



Pictorial index

Exterior






*: If equipped

Pictorial index

Interior



A

Inside rear view mirror P. 47
 Lexus Link System switches* P. 338
 Personal light P. 303
 Moon roof switch* P. 52

Personal light P. 303
 Interior light P. 303



SRS curtain shield airbag P. 66

Interior light P. 303
 Vanity mirror P. 313
 Sun visor P. 312
 Garage door opener switches* P. 329
 Compass* P. 334

*: If equipped

B




Driving position memory switches* P. 35

Door lock switch P. 25

Window lock switch P. 50

Power window switches P. 50

C



*: If equipped

Pictorial index

Instrument panel

Windshield wipers and washer switch P. 126

Multi-information display P. 119

Gauges and meters P. 112

Headlight switch P. 122

Turn signal lever P. 110

Fog light switch P. 125

Seat heater switches* P. 319

Seat heater/ventilator switches* P. 321

Power switch P. 103



Parking brake pedal P. 111

Tilt and telescopic steering control switch P. 46

Coin holder P. 309

"AVS" switch P. 163

Mode select switch P. 107

"TRAC OFF" switch P. 166

Trunk opener main switch P. 29


Glove box P. 307

A



Audio remote control switches P. 259

B



Telephone switch P. 261

"DISP" switch P. 120

Distance switch* P. 134


Cruise control switch
P. 129, 132

Talk switch* P. 272


*: If equipped

*: Refer to "Navigation System Owner's Manual".

C



D



*: If equipped

*: Refer to "Navigation System Owner's Manual".